



Electron Top Mfg.

rev 11/1/2010

Installation Instructions

Always Check Stock # and Color Before Starting Installation



2004-on BMW 645i

BM8170

SG11 Black/Black Sonnendecke Material

BM8170 SG11
Black/Blk
Sonnendeck 11 01



BM8170SG11T0

DATE: 01/07 (MAKE LABELS) ONLY

BM8170 SG11

2004-08 Bmw 645 I

DATE: 01/07







126-15 89th Ave Richmond Hill, NY 11418

No part of this material or accompanying drawings or photos may be reproduced in any form, or by any means, without the express permission of *Electron Top Mfg.*





Electron Top Mfg.







Electron Top Mfg.







Electron Top Mfg.







Electron Top Mfg.







Electron Top Mfg.



Electron Top Mfg.



Electron Top Mfg.



Electron Top Mfg.

